

Dell N1548

Enable/Disable

1. 37  shutdown

```
#configure
(config)#interface gigabitethernet 1/0/37
(config-if-Gi1/0/37)#shutdown
```

2. 37  

```
#configure
(config)#interface gigabitethernet 1/0/37
(config-if-Gi1/0/37)#no shutdown
```

Revision #1

Created 7 June 2022 00:45:21 by artop0420

Updated 8 June 2022 03:35:10 by artop0420