

# Dell N1548에 포트별 Enable/Disable

## 1. 37번 포트 shutdown

```
#configure
(config)#interface gigabitethernet 1/0/37
(config-if-Gi1/0/37)#shutdown
```

## 2. 37번 포트 활성화

```
#configure
(config)#interface gigabitethernet 1/0/37
(config-if-Gi1/0/37)#no shutdown
```

---

🕒Revision #1

★Created 7 June 2022 00:45:21 by artop0420

✎Updated 8 June 2022 03:35:10 by artop0420