

# Dell N1548 snmp설정

n1548 스위치에 snmp 설정

snmp 커뮤니티는 eng로 설정, snmp서버는 192.168.100.10 이라고 하고 설정

```
console>enable
console#configure
Console(config)#hostname master-sw
Console(config)#snmp-server community eng ro
console(config)#snmp-server host 192.168.100.10 eng
console(config)#snmp-server enable traps link
```

---

🔄Revision #1

★Created 7 June 2022 00:43:53 by artop0420

✎Updated 8 June 2022 03:35:10 by artop0420